FREE CHECKLIST MONTAGE & FIX

Diagnosis in 5 minutes: why is your PAX sliding door jamming?

Door jammed, clothes locked in, scratches on the floor? Slide each door slowly all the way open and closed once. Tick what applies.

☐	WHAT YOU SEE	CHECK FIRST	LIKELY	IN THE GUIDE
☐	Gap wider at the top than the bottom (or vice versa)	Spirit level upright against the frame side	Frame not plumb	Ch. 4 → 6
☐	Large gap between the doors (a hand fits through)	Is the front door (longer brackets, wider strip) in the inner track?	Doors in the wrong track	Ch. 7
☐	Small gap, doors from 2022–2024	Is a gasket or brush missing on the edge?	Extra part missing — IKEA customer service	Ch. 10
☐	Jams at one particular spot	Is anything lying in the top or bottom track?	Debris / tracks not parallel	Ch. 9 → 5
☐	Door jumps the track	Anti-lift guard closed? Bottom seated/clicked in?	Not secured / set too high / bent track	Ch. 7 → 6 → 5
☐	Door rolls by itself	Spirit level along the bottom track	Wardrobe not level	Ch. 4
☐	Rattles or bangs	End stops present on the tracks?	Debris / missing stop	Ch. 9
☐	Soft-close doesn't engage	Damper fitted and compatible with the model?	Position / compatibility	Ch. 8
☐	Top track too short/too long	Measure the total width of the frames	Wrong length / frames not flush	Ch. 5

The one rule: always work in this order — **frame → tracks → rollers → dampers.** Turn the rollers first and you only move the problem.

Safety: only take mirror and glass doors off with two people. Anchor the wardrobe to the wall first.

The full guide "Adjusting PAX Sliding Doors Properly" (PDF, 22 pages, €14.90) shows every step: montagefix-berlin.de/en/ratgeber/pax-schiebetueren-einstellen

None of these? In Berlin we recalibrate sliding doors at a fixed price from €65. Photo on WhatsApp to +49 151 29515576.

IKEA® and PAX® are trademarks of Inter IKEA Systems B.V. Independent guide, not affiliated with IKEA.